

AOT120-G SMS Commands

Configuration

Set Domain: SL DPtrack.AOT.com#6000#
Set IP: SL DP111.222.333.444#6000#
Set APN: SL APNconnect.mobilinkworld.com,,#
Mov/Stop: SL INTV30,600 // Movment=30 and Stop time 600 sec

Center Number

Add Center No. SL CP+923001234567# // Center Number must be start +92.....

Kill / Release

Kill: SL YD0 //only center number control allowed
Release: SL YD1 //only center number control allowed

Voice/SOS Number

Add Voice/SOS #1 101#03001234567#
Add Voice/SOS #2 102#03001234567#
Add Voice/SOS #3 103#03001234567#
Delete Voice/SOS #1 D101#
Delete Voice/SOS #2 D102#
Delete Voice/SOS #3 D103#

Check Setting

Check Voice/SOS No. C10# // Check Voice/SOS numbers
Check Configuration SL CX // Check configuration
Check Google link SL URL // Google Location
Check Version SL VR // Check Version
Check CCID: SL ICCID // SIM serial number
Check APN: SL APN // select Auto APN
Check IMEI: SL IE // Check ID
Check Location: SL LC // Check lat/log
Restart: SL RT // Device restart